Component Editor (Right Sidebar)

This panel updates when you select a component.

You can adjust:

- **Type:** Rectangle or Circle
- **Text:** Shown above the component, and rotates with it
- **Text Size:** Size of the text in points (pt)
- **Position:** X / Y coordinates
- **Size:** Width, Height, Diameter
- **Rotation:** In degrees clockwise (e.g., 0°, 18°, 45°, 90°)
- **Function:**
  - Drill Diameter (For Rounded Components): The diameter to create a cut.
  - Drill Width/Length (For Rectangular Cmponents): The drill dimensions to create a cut.
  - Visible Diameter/Visible Width/Visual Length: The dimensions of a *recess area* or *engraved region*, and also determine the spacing between the component and its label text.
    If a **Visible Diameter** value is entered, it takes precedence and the other two values will be ignored.
    Both Rounded and Rectangular components can include *drill* or *visible (recess)* parameters.

You can also **delete** or **duplicate** components from this panel.

Revision #1
Created 2025-11-07 10:45:27 UTC by MIDILLI
Updated 2025-11-07 10:45:40 UTC by MIDILLI